



Mikrofon Guide

Ficksändare:



Handmikrofon:



Headset:



Speak with regular voice in the microphone.
Keep the microphone approx. 2-15 cm from the mouth.

